



## Part Number 57-0455 INSTALLATION INSTRUCTIONS

Fiat Punto 1.2L 8v Mpi 59Bhp Oct 1999...

1. Remove the clip from the front of the air box. (Fig. 1)
2. Unclick the air box intake from the inner wing. (Fig. 2)
3. Remove the two air box securing bolts. (Fig. 3&4)
4. Carefully lift the air box and disconnect the breather hose before removing from the vehicle. (Fig. 5)
5. Fit the plastic elbow into the breather hose as shown. (Fig. 6)
6. Degrease the throttle neck.
7. Fit the filtercharger onto the throttle neck and secure using the #40 hose clip as shown. (Fig. 7)
8. Fit the breather elbow into the small hole in the filtercharger base. (Fig. 8)
9. Carefully expand the flexi cold air hoses and pierce a hole in one of the plastic ends on each hose.
10. Feed the pierced end of each of the flexi cold air hoses over the radiator and secure in to the front grill using two of the plastic ties supplied. (Fig. 9)
11. Position the cold air hoses toward the filtercharger to finish approximately 10cm / 4" away and secure in position using two of the plastic ties supplied. (Fig. 10)
12. Carry out a final height / alignment check of the kit fitment, Installation is now complete.

### Parts list:

- 1 x Filtercharger Element.
- 2 x cold Air Hose Assembly.
- 1 x Literature Pack.

### Fixing kit : -

- 1 x #40 Hose Clip.
- 4 x Plastic Ties.
- 1 x Plastic Elbow.

**WARNING:** Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10

