



Part Number 57-0462 INSTALLATION INSTRUCTIONS

MG ZS120 1.8L 16v Dohc 115Bhp L4 June 2001....

1. Unclip & remove the intake hose from the throttle housing. (Fig. 1&2)
2. Unclip & remove the air box lid / filter from the air box base. (Fig. 3&4)
3. Remove the two securing bolts from the side of the air box base & remove the base from the vehicle. (Fig. 5&6)
4. Carefully lengthen the flexi cold air hose & feed the hose down to the lower spoiler. Secure the top of the cold air hose to the radiator coolant hose using a plastic tie supplied. (Fig. 7)
5. Taking all necessary safety precautions as per manufacturers instructions raise the front of the vehicle. Pierce / drill two 4mm holes in the spoiler trim; secure the cold air hose to the spoiler trim using a plastic tie supplied. (Fig. 8)
6. Assemble the new molded intake pipe using the silicone hose adaptor, rubber filter adaptor, filtercharger & hose clips supplied. (Fig. 9)
7. Fit the new intake assembly to the throttle body & secure using the hose clip supplied. (Fig.10&11)
8. Carry out a final height / alignment check of the kit fitment. Installation is now complete.

Parts list:

- 1 x Filtercharger Element.
- 1 x Molded Intake Pipe.
- 1 x Rubber Filter Adaptor.
- 1 x Silicone Hose Adaptor.
- 1 x Flexi Cold Air Hose Assembly.
- 1 x Literature pack.

Fixing Kit:-

- 3 x Plastic Ties.
- 2 x #44 Hose Clamp.
- 1 x #64 Hose Clamp.

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10



Fig. # 11

