



Part Number 57- 0474 INSTALLATION INSTRUCTIONS

Fiat Stilo 1.6L 16V 4Cyl. 103bhp 2001 On...

Fiat Stilo 1.8L 16V 4Cyl. 133bhp 2001 On...

1. Turn the ignition off & disconnect the vehicle's negative battery cable.
2. Carefully remove the engine cover from the engine. (Fig. 1)
3. **1.6L models only:** Unclip & remove the breather hose from the intake hose. (Fig. 2)
4. Unclip and remove the intake hose from the throttle body. (Fig. 3)
5. Unclip the intake hose from the air box & carefully remove from the car. (Fig. 4)
6. Unbolt the air box from the mounting bracket underneath the battery tray. (Fig. 5)
7. Taking all the necessary safety precautions as per manufactures instructions raise the front of the vehicle.
8. Carefully remove the undertray (if present) from the car.
9. Remove the left front undertray from the car. (Fig. 6)
10. Lift the air box out of its mounting grommets & carefully remove from the car, leaving the intake snorkel in place. (Fig. 7)
11. Fit the new metal adaptor tube & filtercharger to the original intake pipe. Do not fully tighten the intake pipe clamp at this time. (Fig. 8)
12. Fit the nylon conical washer onto the stud located on the metal adaptor tube ensuring that the recess is towards the tube. Secure the new mounting bracket on top of the conical washer using the flat metal washer & nylock nut supplied. (Fig. 9)
13. Carefully feed the intake assembly underneath the car and fit it back to the throttle body using the hose clamp supplied (**1.6L models:**#36 clamp, **1.8L models:**#48 clamp). (Fig. 10)
14. **1.6L models only:** Reconnect the breather hose to the intake hose using the # 10 hose clip supplied. (Fig. 11)
15. Attach the new bracket to the air box mounting bracket underneath the battery tray using the bolt & flat metal washer supplied (rotate the metal adaptor tube until the bracket lines up). Now fully tighten the intake pipe clamp. (Fig. 12)
16. **1.6L models only:** Remove one of the plastic sleeves from the end of the cold air hose and feed this end over the intake snorkel & secure using the plastic tie supplied. **1.8L models only:** Feed the flexi cold air hose into the intake snorkel & secure using the plastic tie supplied. **1.6L & 1.8L models:** Position the other end of the cold air hose to finish approximately 10cm/4" away from the filter. (Fig. 13)
17. Reconnect the vehicles negative cable. Carry out a final check of the height / alignment of the K&N induction system before starting the engine. Installation is now complete.

Parts list:

- 1 x Filtercharger Element.
- 1 x #48 Hose Clamp.
- 1 x Cold Air Hose Assembly.
- 1 x Studded Metal Adaptor Tube.
- 1 x Literature Pack.
- 1 x Fixing Kit :
 - 1 x #10 Hose Clamp.
 - 1 x #36 Hose Clamp.
 - 1 x #48 Hose Clamp.
 - 1 x Mounting Bracket.
 - 1 x Bolt M6 x 20
 - 1 x Nut Nylock M6
 - 2 x Flat Metal Washer
 - 1 x Nylon Conical Washer.
 - 1 x Plastic Tie.

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10



Fig. # 11



Fig. # 12



Fig. # 13

