



## Part Number 57- 0480 INSTALLATION INSTRUCTIONS

Fiat Stilo Abarth 2.4L 20V 5 Cyl. 170 bhp 2001 On...

We recommend that a professional mechanic using a ramp should fit this kit.

1. Unscrew the two bolts that attach the mass air sensor to the air box. (Fig. 1)
2. Taking all the necessary safety precautions as per manufactures instructions raise the front of the vehicle.
3. Carefully remove the undertray from the vehicle. (Fig. 2)
4. Remove the left front undertray from the vehicle. (Fig. 3)
5. Unscrew the air box mounting bolt from the mounting underneath the battery tray. (Fig. 4)
6. Lift the air box out of its mounting grommets and carefully remove from the vehicle. (Fig. 5)
7. Carefully remove the intake snorkel from the vehicle. (Fig. 6)
8. Assemble the saddle bracket to the mounting bracket using the countersunk screw, conical washer, flat metal washer, nylock nut and #44 hose clip supplied. (Fig. 7)
9. Fit the saddle bracket assembly to the air box mounting point using the M6 bolt and flat metal washer supplied. (Fig. 8)
10. Assemble the plastic molded intake tube together with the rubber adaptor and silicon sleeve using the #44 hose clip supplied. (Fig. 9)
11. Fit the plastic molded intake tube assembly through the saddle bracket onto the mass air sensor and firmly tighten the #44 hose clip. (Fig. 10)
12. Put the precharger wrap over the filter element. (Fig. 11)
13. Fit the filter onto the rubber adaptor using the #64 hose clip supplied. (Fig. 12).
14. Ovalize the end of the cold air hose without plastic sleeve and feed it into the slam panel, secure the cold air hose to the radiator hose using a long plastic tie supplied. (Fig. 13)
15. Position the end of the cold air hose to finish approximately 4"/10cm away from the filter element. (Fig. 14)
16. Carry out a final check of the height/alignment of the K&N induction system before starting the engine. Installation is now complete.

### Parts list:

- 1 x Filtercharger Element.
- 1 x Precharger Wrap.
- 1 x Plastic Molded Intake Tube.
- 1 x Rubber Adaptor.
- 1 x Silicon Sleeve.
- 1 x Cold Air Hose Assembly.
- 1 x Literature Pack.
- 1 x Fixing Kit :-
  - 2 x # 44 Hose Clips.
  - 1 x # 64 Hose Clip.
  - 1 x Mounting Bracket.
  - 1 x Saddle Bracket.
  - 1 x Bolt M6 x 16.
  - 1 x Countersunk Screw.
  - 1 x Nut Nylock M6.
  - 2 x Flat Metal Washers.
  - 1 x Conical Washer.
  - 1 x Plastic Tie.

**WARNING:** Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



# Part Number 57- 0480 INSTALLATION INSTRUCTIONS

Fiat Stilo Abarth 2.4L 20V 5 Cyl. 170 bhp 2001 On...



Fig. # 9



Fig. # 10



Fig. # 11



Fig. # 12



Fig. # 13



Fig. # 14



Fig. # 16