



# Part Number 57-0508 INSTALLATION INSTRUCTIONS

## Fiat Punto 1.2L 16v Dohc 86bhp May'97-Oct'99

1. Disconnect the negative terminal from the battery.
2. Unclip & remove the intake hose from the air box assembly. (Fig. 1)
3. Unclip & remove the intake hose from the throttle housing. (Fig. 2)
4. Unclip & remove the breather hose from the side of the intake hose. Remove the intake hose from the vehicle. (Fig 3)
5. Taking the necessary safety precautions as per manufacturers instructions raise the front of the vehicle.
6. Remove the 3 screws securing the plastic grille trim to the side of the radiator & carefully remove the trim from the vehicle. (Fig. 4)
7. Carefully expand the flexi cold air hose & feed the hose down to the lower grille. Secure the hose to the grille using a plastic tie supplied. (Fig. 5)
8. Feed the other end of the cold air hose under the battery tray & secure to the side harness using a plastic tie supplied (ensure sufficient clearance between the hose & gear selector rods). (Fig. 6)
9. Assemble the new intake pipe using the rubber filter adaptor, stepped silicone adaptor hose & #48 hose clamp supplied. (Fig. 7)
10. Fit the new filtercharger to the rubber filter adaptor & secure using the #64 hose clamp supplied. (Fig. 8)
11. Screw the barbed vent adaptor into the threaded hole located in the side of the new intake pipe. (Fig. 9)
12. Fit the new intake pipe assembly to the throttle housing & secure using the #44 hose clamp supplied (Ensure sufficient clearance between the filtercharger & the fuel hoses). (Fig.10)
13. Fit the new silicone breather hose to the original breather plastic adaptor tube. (Fig. 11)
14. Join the other end of the silicone breather hose to the barbed vent adaptor on the new intake pipe. (Fig.12)
15. Position the end of the cold air hose to finish approx. 4" / 10cm from the filtercharger.
16. Reconnect the negative battery terminal.
17. Carry out a final check of the height / alignment of the K&N induction system before starting the engine. Installation is now complete.

**Parts list:**

- 1 x Filtercharger Element.
- 1 x Plastic Intake Tube.
- 1 x Rubber Filter Adaptor.
- 1 x Silicone Adaptor Hose.
- 1 x Cold Air Hose Assembly.
- 1 x Literature Pack.

**Fixing kit: -**

- 1 x Silicone Breather Hose.
- 1 x Barbed Vent Adaptor.
- 1 x #48 Hose Clamp.
- 1 x #44 Hose Clamp.
- 1 x #64 Hose Clamp.
- 3 x Plastic Ties.

**WARNING:** Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10



Fig. # 11



Fig. # 12