



Part Number 57-0415 INSTALLATION INSTRUCTIONS

Fiat Punto HGT 1.8L 16v, 4cyl, 129BHP.

Oct'99 On...

1. Unclip & disconnect the flexi intake hose from the air box lid. (Fig. 1)
2. Unclip the flexi intake hose from the throttle housing & remove from the vehicle. (Fig. 2)
3. Unscrew & remove the air box lid from the vehicle. (Fig. 3)
4. Following manufacturers instructions carefully remove the battery from the vehicle.
5. Remove the 3 bolts securing the battery tray to the vehicle. (Fig. 4)
6. Remove the 2 bolts securing the air box base and carefully remove the air box base from the vehicle. (Fig. 5)
7. Assemble the saddle bracket to the 'L' bracket using the tapered screw, conical washer, flat washer & M6 nylock nut supplied. (Fig. 6)
8. Mount the 'L' bracket to the inner air box mounting using the original mounting bolt. (Fig.7)
9. Refit the battery tray to the vehicle using the original bolts.
10. Reconnect the battery following the manufacturers instructions.
11. Fit the plastic adaptor tube into the air box end of the original flexi intake hose and secure using the #44 hose clip supplied.
12. Fit the rubber filter adaptor on to the plastic tube and refit the flexi intake hose to the vehicle using the original hose clip. (Fig. 8)
13. Place the rubber filter adaptor into the saddle bracket. (Fig. 9)
14. Fit #64 hose clip supplied around the saddle bracket.
15. Fit the filter charger onto the rubber adaptor and firmly tighten the hose clip around the saddle bracket and filter neck. (Fig 10)
16. Carry out a final height / alignment check of the kit fitment. Installation is now complete.

Parts list:

- 1 x Filtercharger Element.
- 1 x #64 Hose Clip.
- 1 x Rubber Filter Adaptor.
- 1 x Plastic Adaptor Tube.
- 1 x Fixing Kit :-
 - 1 x #44 Hose Clip.
 - 1 x Tapered Screw.
 - 1 x Conical Washer.
 - 1 x M6 Nylock Nut.
 - 1 x Flat Washer.
 - 1 x Powder Coated 'L' Bracket.
 - 1 x Saddle Bracket

WARNING: Before starting the engine carry out a final fitment check of the K&N performance kit. It will be necessary for all intake systems to be checked periodically for realignment, clearance and tightening of all connections. Failure to follow the above instructions or proper maintenance may void the warranty.



Fig. # 1



Fig. # 2



Fig. # 3



Fig. # 4



Fig. # 5



Fig. # 6



Fig. # 7



Fig. # 8



Fig. # 9



Fig. # 10